

When to Change a Harp String

The harp string should be changed when:

1. The string is broken or missing
2. The string is discolored
3. The string is wound all the way to the neck
4. The wrong string type was used
5. The nylon wrap winds onto the tuning pin
6. The gut string is starting to fray
7. The string has dents, fraying, or discoloration where the lever or pedal discs press on it
8. Reduced sound quality (dead string)
9. Time – Is the string too old and stretched out?